

Ordering guide for C50-IP air valves for raw sewage with inflow prevention

Order code	Waterworks	Valve size (inches)	Model C50	Body material (GRP)	Inflow protection	Inlet connection (BP - BSP BD - Flanged T/D)
WW-2-C50-P-IP-BP	WW	2	C50	P	IP	BP
WW-2-C50-P-IP-BD	WW	2	C50	P	IP	BD
WW-3-C50-P-IP-BP	WW	3	C50	P	IP	BD
WW-4-C50-P-IP-BP	WW	4	C50	P	IP	BD



Order code	Waterworks	Valve size (inches)	Model C50	Body material (DI)	Inflow protection	Inlet connection (BP - BSP BD - Flanged T/D)
WW-2-C50-J-IP-BP	WW	2	C50	J	IP	BP
WW-3-C50-J-IP-BD	WW	3	C50	J	IP	BD
WW-4-C50-J-IP-BD	WW	4	C50	J	IP	BD



Order code	Waterworks	Valve size (inches)	Model C50	Body material (316 St Stl)	Inflow protection	Inlet connection (BP - BSP BD - Flanged T/D)
WW-2-C50-G-IP-BP	WW	2	C50	G	IP	BP
WW-3-C50-G-IP-BD	WW	3	C50	G	IP	BD
WW-4-C50-G-IP-BD	WW	4	C50	G	IP	BD

