

Ordering guide for C50-SP air valves for raw sewage with surge prevention

Order code	Waterworks	Valve size (inches)	Model C50	Body material (GRP)	Surge protection	Inlet connection (BP - BSP BD - Flanged T/D)
WW-2-C50-P-SP-BP	WW	2	C50	P	SP	BP
WW-2-C50-P-SP-BD	WW	2	C50	P	SP	BD
WW-3-C50-P-SP-BP	WW	3	C50	P	SP	BD
WW-4-C50-P-SP-BP	WW	4	C50	P	SP	BD



Order code	Waterworks	Valve size (inches)	Model C50	Body material (DI)	Surge protection	Inlet connection (BP - BSP BD - Flanged T/D)
WW-2-C50-J-SP-BP	WW	2	C50	J	SP	BP
WW-3-C50-J-SP-BD	WW	3	C50	J	SP	BD
WW-4-C50-J-SP-BD	WW	4	C50	J	SP	BD



Order code	Waterworks	Valve size (inches)	Model C50	Body material (316 St Stl)	Surge protection	Inlet connection (BP - BSP BD - Flanged T/D)
WW-2-C50-G-SP-BP	WW	2	C50	G	SP	BP
WW-3-C50-G-SP-BD	WW	3	C50	G	SP	BD
WW-4-C50-G-SP-BD	WW	4	C50	G	SP	BD

