


Ordering guide for C50-SP air valves for raw sewage with surge prevention


Order code	Waterworks	Valve size (inches)	Model C50	Body material (GRP)	Surge protection	Inlet connection (BP - BSP BD - Flanged T/D)
WW-2-C50-P-SP-BP	WW	2	C50	P	SP	BP
WW-2-C50-P-SP-BD	WW	2	C50	P	SP	BD
WW-3-C50-P-SP-BP	WW	3	C50	P	SP	BD
WW-4-C50-P-SP-BP	WW	4	C50	P	SP	BD



 Order code	Waterworks	Valve size (inches)	Model C50	Body material (DI)	Surge protection	Inlet connection (BP - BSP BD - Flanged T/D)
WW-2-C50-C-SP-BP	WW	2	C50	C	SP	BP
WW-2-C50-C-SP-BD	WW	2	C50	C	SP	BD
WW-3-C50-C-SP-BD	WW	3	C50	C	SP	BD
WW-4-C50-C-SP-BD	WW	4	C50	C	SP	BD



AS4883-2017 approved

 Order code	Waterworks	Valve size (inches)	Model C50	Body material (316 St Stl)	Surge protection	Inlet connection (BP - BSP BD - Flanged T/D)
WW-2-C50-N-SP-BP	WW	2	C50	N	SP	BP
WW-2-C50-N-SP-BD	WW	2	C50	N	SP	BD
WW-3-C50-N-SP-BD	WW	3	C50	N	SP	BD
WW-4-C50-N-SP-BD	WW	4	C50	N	SP	BD



AS4883-2017 approved